



LG Risio Battery Replacement

This guide will walk you through how to replace the battery for the LG Risio.

Written By: Erika Heppner



INTRODUCTION

If your LG Risio battery isn't holding charge, or the battery is overheating while charging, use this guide to replace it.

TOOLS:

- [iFixit Opening Tools \(1\)](#)

Step 1 — Back Panel



- Use a plastic opening tool to separate the back panel from the device.
- Remove the back panel.

Step 2 — Battery



- Place your thumb along the bottom of the battery and pry upwards to remove.

To reassemble your device, follow these instructions in reverse order.