



LG Stylo 3 Plus Motherboard Replacement

How to remove the motherboard of the LG Stylo 3 Plus.

Written By: Patricia Pires Dias



INTRODUCTION

Use this guide to replace the motherboard of your LG Stylo 3 Plus.

TOOLS:

- [Tweezers \(1\)](#)
- [Phillips #000 Screwdriver \(1\)](#)
- [iFixit Opening Tools \(1\)](#)

Step 1 — Back Cover



ⓘ Power off the phone before beginning disassembly.

- Place the phone face down.
- Insert a fingernail or a plastic opening tool into the gap on the side of the phone.
- Carefully slide your finger or the tool throughout the edge of the phone to ease the back case off.

Step 2 — Battery



- Place the back cover off to the side.
- Insert the opening tool into the small gap below the battery.
- Carefully pop the battery out to prevent damage.

Step 3 — Rear Camera




- Remove the twelve 4mm screws using the Phillips #000 screwdriver.
- Use the plastic opening tool to remove the inner case.
- Carefully remove the inner case.

Step 4



- Use your fingernail or the plastic opening tool to flip the flex cable.
- Use the precision tweezers to carefully grasp and pull out the camera.

Step 5 — Front Camera



- Carefully flip open the flex cable box with the plastic opening tool.
- Using precision tweezers, carefully lift the front camera off the device.

Step 6 — Motherboard



- Gently flip open the flex cable box using a blue plastic opening tool.
- Carefully remove the motherboard with your hands or a blue plastic opening tool.

⚠ Make sure all parts are secure while taking out motherboard.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-02-16 06:27:44 PM (MST).

