



# LG VX6100 Front Case Replacement

This guide will show how to remove the front casing of the phone.

Written By: Ryan Bishop



## INTRODUCTION

These steps show how to remove the phone's front case. This allows access to many of the components located on the outer face of the phone.

### TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [Push Pin](#) (1)
- [Tweezers](#) (1)
- [iFixit Opening Tools](#) (1)

## Step 1 — Front Case



- Remove the four grey plugs using either tweezers or a push pin.

## Step 2



- Remove the four screws that are now exposed using a Phillips #00 screwdriver.

*ⓘ* Be sure to put the screws in a safe place as they are very small and easy to lose.

## Step 3



- Once all the screws have been removed, use a plastic opener tool to pry the case from the rest of the phone.
- Insert the opener tool into the seem between the case and the phone. Apply pressure to separate the two pieces.
- Do this across the entire length of the seem until the case is no longer attached to the phone.

## Step 4



- The case can now be removed and the interior of the front is accessible.

To reassemble your device, follow these instructions in reverse order.