



Lenovo Edge Thinkpad E431 Screen Replacement

This guide will display the steps on how to change the 14.0 inch LCD screen on the Lenovo Thinkpad Edge E431.

Written By: Abdullah Muhammad Ashfaq Nadir



This document was generated on 2019-09-23 10:16:43 AM (MST).

INTRODUCTION

This guide will show you how to replace the screen on a Lenovo ThinkPad Edge E431 laptop.

TOOLS:


- [Phillips #00 Screwdriver](#) (1)
- [Spudger](#) (1)
- [iFixit Opening Tools](#) (1)
- [Magnetic Project Mat](#) (1)
- [Phillips #0 Screwdriver](#) (1)

Step 1 — Battery




- Remove the 2mm Phillips #00 screw from the battery cover.
- Lift the battery cover out of its slot.

Step 2




- Disconnect the battery cable.

Step 3 — Screen




- Use the pointed end of a spudger to remove the two screw covers from the bottom corners of the display.

Step 4



- Remove the two 2mm Phillips #00 screws found at the bottom corners of the display.

Step 5



- Separate the front bezel from the display using the plastic opening tool.

Step 6



- Remove the four 2mm Phillips #00 screws from the screen.

Step 7



- Lay the screen flat on top of the keyboard.

Step 8



- Peel up the adhesive tape to unlatch the metal retaining bracket on the display cable.

To reassemble your device, follow these instructions in reverse order.