




Lenovo G50-80 80E5 Keyboard Replacement

Removing the keyboard for replacement or for further disassembly.

Written By: Victor



 **TOOLS:**


- [Phillips #0 Screwdriver \(1\)](#)
- [iFixit Opening Tools \(1\)](#)

Step 1 — Keyboard



- Locate the 3 screws on the bottom, securing the keyboard.
- One Screw will be located under Lenovo sticker. Break sticker to gain access to screw.

Step 2




- Starting on side, gently pry up using spudger.

Step 3




- Continue prying around top of keyboard

Step 4




- Once the top of keyboard is loose, gently lift up

Step 5





- lift up bottom of keyboard slightly, to access keyboard ribbon

Step 6



- Using tweezers, lift up clip to remove keyboard ribbon cable.

Step 7



- Keyboard ribbon cable removed
- Once ribbon is removed, keyboard can be lifted out

To reassemble your device, follow these instructions in reverse order.