



Lenovo G500S Touch Battery Replacement

Use this guide to replace the battery in your Lenovo G500s.

Written By: Christopher Foster



INTRODUCTION

If you find that your computer fails to hold a charge or isn't turning on, it may be time to replace the battery. This simple guide will show you the steps to remove the battery from the device.

Step 1 — Battery



ⓘ Make sure that your device is powered off and unplugged from the power source.

- Flip your device over so that the back is facing you.
- Using your fingers, push the tabs in opposite directions to eject the battery.
- Remove the battery from the device.

To reassemble your device, follow these instructions in reverse order.