




# Lenovo G580 Keyboard Keys Replacement

How to replace keyboard single keys if they are missing or damaged. This guide will help you change the keys easily within seconds.

Written By: khalid massad



## INTRODUCTION

Keyboard keys can be damaged through extensive use or spills. It is important to be able to replace missing keys as a keyboard is unusable without all keys in working order. This is a simple task that only requires a spudger and a few minutes of time.

### TOOLS:

- Prying and Opening Tool Assortment (1)

### PARTS:

- Lenovo G580 replacement keyboard key (1)

## Step 1 — Keyboard Key



- For damaged keys, start by having a prying tool handy.

## Step 2



- Start by pushing a plastic opening tool gently under the key.

**⚠** Do not force the plastic opening tool as this will damage the keyboard mechanisms.

## Step 3



- Gently pull upwards with the prying tool until the key comes off.
- Use your hand to remove the key once the key is fully released.

## Step 4



- To replace the key, place the key above its mechanism and gently press it into place.

To reassemble your device, follow these instructions in reverse order.