



Lenovo IdeaPad 100s-14IBR Battery Replacement

This guide will help the users fix issues with the battery that is found in the Lenovo IdeaPad 100S-141BR.

Written By: Mohammed Younis




INTRODUCTION

This guide will help the users fix issues with the battery that is found in the Lenovo IdeaPad 100S-141BR.

TOOLS:

- [Spudger](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Battery



- Remove the eight 4mm PH00 screws.
- Remove the four 2mm PH00 screws.


Step 2



- Use the nylon spudger to loosen the back cover from the back of the device.


⚠ You may hear a bit of a snapping sound, but this is normal.

Step 3



- Remove six 4mm Phillips #00 screws.
- Disconnect the wires that connect the battery to the laptop's motherboard.

Step 4



- Use a nylon spudger to pry the battery up and out of the device.

To reassemble your device, follow these instructions in reverse order.