



# Lenovo IdeaPad 110-15ISK Upper Case Replacement

Replace your broken or malfunctioning upper case.

Written By: Tyler




## INTRODUCTION

If there is any physical damage done to the upper case, a replacement may be required based on the condition of the laptop. Follow the guide to replace the upper case of the laptop.

### TOOLS:


- [Spudger \(1\)](#)
- [iFixit Opening Tools \(1\)](#)
- [Phillips #1 Screwdriver \(1\)](#)

## Step 1 — Keyboard




- Use the plastic opening tool to pry the keyboard up and away from the bottom assembly.

## Step 2



- Next disconnect the keyboard cable by using the tip of the spudger or your finger to lightly push out the ribbon from the contact port.
- Completely remove the keyboard from the bottom assembly.

## Step 3 — Optical Drive




- Using a Phillips #1 screwdriver, unscrew the one 5.0mm screw on the back panel.

## Step 4



- Flip the laptop to its back and the optical drive is located at the top left corner.
- Remove the optical CD DVD drive by lightly pulling it out of the assembly.

## Step 5 — Upper Case



- Place the laptop bottom facing up.
- Using a Phillips #1 screwdriver, remove the ten 6.0mm screws on the back panel.
- Flip the computer back to top facing.

## Step 6



- Separate the top case from the bottom using a plastic opening tool.
- Continue prying the top and bottom case from each other all around the perimeter of the laptop.

To reassemble your device, follow these instructions in reverse order.