



Lenovo IdeaPad 120s-14IAP Back Cover Replacement

How to replace a Lenovo IdeaPad 120s-14IAP back cover.

Written By: Kristen Gismondi



 **TOOLS:**

- [T5 Torx Screwdriver \(1\)](#)
- [Jimmy \(1\)](#)

Step 1 — Back Cover



- Orient the laptop so the top is laying flat on your work surface.
- Remove ten 1.5mm Torx T5 screws from the back of the laptop.

Step 2



- Insert the Jimmy along the edge of the back cover and gently pry.
- Run the Jimmy all the way around the edge of the back cover and remove the back cover once it is no longer secure.

To reassemble your device, follow these instructions in reverse order.