




Lenovo IdeaPad 310 Touch-15ISK Fan Replacement

This guide will show you how to disassemble your laptop in order to replace the fan.

Written By: msegundo23







TOOLS:


- [Phillips #0 Screwdriver](#) (1)
- [Spudger](#) (1)
- [Tweezers](#) (1)

Step 1 — Fan





- Flip laptop over
- Remove 13 screws to remove bottom. Size: Phillips #0
- Remove extra 3 screws from RAM port. Size: Phillips #0

Step 2






- Disconnect keyboard and touchpad
- Remove CD drive


Step 3




- Flip laptop back over
- Using a plastic spudger, pry between the keyboard panel and bottom panel on all 4 sides.

Step 4



- Remove 4 screws and tabs holding motherboard
-  Be sure to disconnect fan tab on the bottom of the motherboard

Step 5



- Remove 1 fan screw. Size: Phillips #0

To reassemble your device, follow these instructions in reverse order.