




Lenovo IdeaPad 310 Touch-15ISK Speaker Replacement

This will show you how to disassemble your laptop in order to replace the speakers.


Written By: msegundo23



 **TOOLS:**



- **Phillips #0 Screwdriver** (1)
- **Spudger** (1)
- **Tweezers** (1)

Step 1 — Speaker



- Flip laptop over and remove 13 screws from the bottom panel.
- Remove 3 screws from RAM port.



Step 2



- Disconnect keyboard and touchpad.
- Remove CD port.




This document was generated on 2019-10-12 01:59:28 PM (MST).

Step 3




- Flip laptop back over
- Using a plastic spudger, pry between the keyboard panel and bottom panel on all 4 sides.

Step 4



- Remove 4 screws and tabs holding motherboard
- Be sure to disconnect fan tab on the bottom of the motherboard

Step 5



- ⓘ Removing battery is not necessary to change speakers
- Lift speakers out of their holding place and replace with new ones.

To reassemble your device, follow these instructions in reverse order.