



# Lenovo IdeaPad Z570 Disc Drive Replacement

This guide will show how to replace the disc drive on the Lenovo IdeaPad Z570.

Written By: Daniel Lopes



## INTRODUCTION

Before proceeding with this guide make sure to remove the battery. Also make sure to be in an open space with ample desktop space when proceeding.

### TOOLS:

- [Phillips #0 Screwdriver \(1\)](#)

## Step 1 — Battery



- Place the laptop face down with the battery facing away from you

## Step 2



- Flip the right switch right-bound

## Step 3



- Hold the left switch.

## Step 4



- Push the battery forward lightly to remove it while holding the left switch.

## Step 5 — Disc Drive



- Place the laptop face down with the battery slot facing away from you.

## Step 6



- Loosen all seven 3mm screws from the back panel using a Phillips #0 screwdriver.
- *(i)* These screws cannot be removed from the device.
- Remove the back panel from the device.

## Step 7



- Remove the 3 mm Phillips #0 screw located on the left hand side that holds the disc drive in place.

## Step 8



- Gently remove the disc drive from the left hand side of the laptop.

To reassemble your device, follow these instructions in reverse order.