





Lenovo Laptop b590 LCD Replacement

Written By: Pavel Amelyanenka



Step 1 — Remove the battery



- Pull right trigger and unlock the battery.

Step 2



- Insert Wisdom here

Step 3




- Insert wisdom here

Step 4



- Insert wisdom here

Step 5




- Insert wisdom here

Step 6




- Insert wisdom here

Step 7




- Insert wisdom here

Step 8




- Insert wisdom here

Step 9



- Insert wisdom here

Step 10



- Insert wisdom here

To assemble the device, follow the instructions in reverse order.