




Lenovo Legion Y530-15ICH Battery Replacement

How to replace the battery in a Lenovo Legion Y530-15ICH.

Written By: Kaylie Klausing



INTRODUCTION

If your Lenovo Legion Y530-15ICH isn't powering on or holding a charge then you should use this guide to replace the battery.

The battery provides power to the rest of the computer. If your computer won't power on, you may [have a faulty power cord or just need to restart your computer](#). Your problem may be due to a faulty battery or your battery may also be [swollen](#).

Please make sure the laptop is powered off completely and unplugged before beginning.

TOOLS:

- [iFixit Opening Picks set of 6 \(1\)](#)
- [JIS #1 \(1\)](#)

Step 1 — Back Cover



⚠ Ensure the device is powered off.


- Remove five 7mm screws using the JIS #1 screwdriver.
- Remove six 4mm screws using the JIS #1 screwdriver.

Step 2




- Carefully pry the back-cover off the computer using an iFixit Opening Pick.
- ⓘ Start at the corner of the laptop and work your way around the side. Gently pull up on the cover until it detaches.

Step 3 — Battery



- Remove five 4mm screws holding the battery in place with a JIS #1 screwdriver.

Step 4



- Unplug the cable that connects that battery to the rest of the computer.
- Now you can safely remove the battery.

To reassemble your device, follow these instructions in reverse order.