




Lenovo N20p Chromebook Battery Replacement

Replace a faulty battery in the Lenovo N20p Chromebook.

Written By: Shihao Cao



INTRODUCTION

After a period of time or use, the battery may have issues and lose power after a charge. This guide will explain how to remove the battery from the Lenovo N20p Chromebook.

TOOLS:

- [Spudger](#) (1)
- [Metal Spudger](#) (1)
- [Phillips #0 Screwdriver](#) (1)
- [Phillips #00 Screwdriver](#) (1)

Step 1 — Keyboard



⚠ Power down the Chromebook before starting any repair.

- Remove the two 3.5 mm Phillips #0 screws using a screwdriver.
- *i* It is only necessary to remove these two screws to complete this step.


Step 2



- Use the hook of the metal spudger to carefully lift up the keyboard.

 Lift the keyboard carefully. If you lift too quickly, it might break the two cables that connect the keyboard to the motherboard.

Step 3




- Carefully, disconnect the keyboard cable from the motherboard carefully by pulling on the blue tab of the cable.
- You will now be able to replace the keyboard.

Step 4 — Battery





- Remove the two rubber feet of the back of the Chromebook using a metal spudger.
- Remove six bottom 3.5 mm Phillips #0 screws and two top 5 mm Phillips #1 screws.

Step 5



- Remove all nine 3.5 mm Phillips #00 screws using a screwdriver.

Step 6



- Disconnect the battery cable from the motherboard.
- Disconnect the touch-pad cable from the motherboard.

Step 7




- Use the metal spudger along the seam between the keyboard and the bottom of the Chromebook to lift up and remove the palm rest assembly.
- It is normal for it to click loudly when it is released. Corner tags will be harder to release than other tags and will make a loud sound.

Step 8



- Disconnect the USB cable from the motherboard by pulling the blue tab out of the cable.
- Remove all five 3.0 mm Phillips #00 screws which connect the battery and motherboard.

Step 9



- Remove the battery.

(i) It is helpful to lift and hold the battery as shown.

To reassemble your device, follow these instructions in reverse order.