




Lenovo ThinkPad T410s Hard Drive Replacement

This guide will show how to replace the hard drive of the Lenovo ThinkPad T410s.

Written By: Jacob Murillo




INTRODUCTION

This guide will show how to replace the hard drive of the Lenovo ThinkPad T410s.

TOOLS:


- [Phillips #0 Screwdriver \(1\)](#)

Step 1 — Battery



- Flip the laptop over.
- Push and hold the locking switch to the left.
- Pull the battery out with your other hand.

Step 2 — Hard Drive




- Remove the single Phillips #0 screw that secures the hard drive cover.

Step 3



- Flip the black plastic tab out.

Step 4



- Pull the hard drive out.

To reassemble your device, follow these instructions in reverse order.