



Lenovo ThinkPad T580 Case Replacement

This guide will show how to replace the bottom case on a Lenovo ThinkPad T580.

Written By: Ben Elkayam



INTRODUCTION

Welcome to the bottom case replacement guide for the Lenovo Thinkpad T580.

This guide will detail the steps necessary to replace the external bottom case.

The most common reasons why this component would need to be replaced is because:

- The case is old and damaged
- The case is entirely broken

There are no specialized skills required for replacing the bottom case.

TOOLS:

- [iFixit Opening Picks set of 6](#) (1)
- [Phillips #000 Screwdriver](#) (1)

Step 1 — External Battery



- Arrange the laptop so it is upside-down and the front is facing away from you. This will get the battery directly in front of you.

Step 2



- Pull the slides away from the center of the laptop to release the battery.

Step 3



- Pull the battery directly out of the socket.

Step 4 — Bottom Case



- Using a Phillips #000 screwdriver, unscrew eight 3.3 mm screws on the bottom of the laptop.
- The screws will not come out of the case.

Step 5



- Run a plastic opening pick along the crease of the computer all the way around.
- Once all the clips are released, remove the bottom cover.

To reassemble your device, follow these instructions in reverse order.