



Lenovo ThinkPad X100e Battery Replacement

Use this guide to remove and replace the battery on the Lenovo ThinkPad X100e.

Written By: Jose Orlando Guerra



INTRODUCTION


This guide is for removing the ThinkPad X100e's battery and replacing it with a new one.

Step 1 — Battery



- Flip the computer upside down.
- *i* The rectangle on the image shows the battery on this computer.

Step 2



- Use your fingers to push both battery release tabs on the back of the computer.

Step 3



- Push the battery out and place to the side.

To reassemble your device, follow these instructions in reverse order with the new battery.