



Lenovo ThinkPad Yoga 14 20FY Battery Replacement

This guide explains how to easily and safely locate and remove the battery from your Lenovo Thinkpad Yoga.

Written By: Jacob Singer



INTRODUCTION


This guide explains how to safely remove the battery from your Lenovo Thinkpad Yoga 14 20FY.



TOOLS:

- [Mako Driver Kit - 64 Precision Bits](#) (1)
-

Step 1 — Back Cover



- Remove the indicated nine M2 x 6 mm nylon-coated screws using a Phillips head screwdriver.

i The screws do not come all the way out. Do not force them out.

Step 2



- After removing all of the screws, gently lift up on all covers to remove the back plate and reveal the interior of the device.

Step 3 — Battery




- Locate the battery of the laptop.

Step 4



- To remove the battery, use a Phillips head screwdriver to unscrew four screws. They are located at the four corners.

Step 5



- There will also be a clip that attaches the battery to the rest of the laptop. Unclasp the clip from its holding to completely free the battery.

Step 6



- Once all wires are detached from the rest of the computer, remove the battery from the laptop and replace.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-10-04 09:52:04 AM (MST).

