




Lenovo ThinkPad Yoga 260 Repair Heat Sink Replacement

If you have a faulty heat sink, this guide will show you how to replace it.

Written By: Daniel Fernandez



INTRODUCTION

The heat sink regulates the temperature of the laptop. If you have a faulty heat sink, this guide will show you how to replace it.

TOOLS:

- [Phillips #1 Screwdriver \(1\)](#)
- [iFixit Opening Tools \(1\)](#)

Step 1 — Back Cover



(i) Ensure the device is off and unplugged.

- Remove the stylus from its port and set aside.

Step 2



- Using a Phillips #1 screwdriver, gently unscrew the eight 1.3 mm Phillips #1 screws until you hear an audible click.

(i) The screws will not separate from the bottom cover when loose.


Step 3



(i) The bottom cover is attached via several plastic clips located around the edges of the bottom cover.


- Using a plastic opening tool, gently pry the bottom cover from the laptop.
- Work the plastic opening tool around the edges of the bottom cover undoing all of the plastic clips, as shown in the picture.

Step 4



- Place your fingers around the edges of the cover and remove it.



Step 5 — Heat Sink



⚠️ Heatsink should be cool to the touch.


- Using your index fingers, gently remove the fan's power connection.

Step 6



- Using a Phillips #1 screwdriver, remove the four 1.3 mm Phillips #1 screws and set them aside.
- *(i)* The screws will not separate from the mounting when loose.

Step 7



- Using your index finger and thumb, gently pry the cooler from its mountings and remove the assembly.

To reassemble your device, follow these instructions in reverse order.