



Lenovo Thinkpad T410i Screen Bezel Replacement

How to remove the screen bezel for the LCD screen and integrated webcam repair guides for the Lenovo Thinkpad T410i.

Written By: Gabriel Cordova



This document was generated on 2019-09-23 04:38:22 AM (MST).

INTRODUCTION

This is just a prerequisite guide for the webcam and screen replacement guides.

TOOLS:

- Spudger (1)
- Phillips #0 Screwdriver (1)

PARTS:

- [Lenovo Thinkpad T410i Screen Bezel](#) (1)

Step 1 — Screen Bezel



- Use a spudger to remove the plastic covers from the LCD screen.

Step 2



- Remove the two 6.0mm screws on each side using Philips #0 head screwdriver as shown in the picture.

Step 3



- Use a spudger to separate the bezel of the LCD screen.

Step 4



- Continue along the edges lifting up and prying off the plastic LCD bezel.

To reassemble your device, follow these instructions in reverse order.