




Lenovo Thinkpad Tablet 1838 Touch Screen Replacement

How to replace a Lenovo Thinkpad Tablet 1838 touch screen.

Written By: Michael Gaskey



INTRODUCTION

This guide is used for replacing a touch screen on the Lenovo Thinkpad Tablet Touch screen. This task is needed if the screen has been cracked or damaged, follow this detailed guide and your Thinkpad will be good as new in just 30 minutes.

TOOLS:

- [Spudger](#) (1)
- [Phillips #00 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)

Step 1 — Touch Screen



- Remove the button with the arrow pointing left.

- (i)* You can do this by putting the spudger underneath the button and pulling up.

Step 2




- Remove the two 10mm Phillips #00 screws.

Step 3





- Use an opening tool to pry open and disconnect the screen from the rest of the tablet.
- *i* Be gentle and work from the bottom of the tablet in counterclockwise direction.

Step 4




- Open the tablet screen to the left, making sure not to disconnect any of the wires connecting the screen to the tablet.

Step 5



- Disconnect the ribbon connector by pulling up on the white gate.
- Then just simply pull the wire to the left to disconnect it.

Step 6



- Disconnect the last ribbon connector using your fingernails to grip the ends of the connector and gently pull to the left.
- There might be some tape over the connector that you will have to remove.

Step 7



- You have successfully removed the old screen.

To reassemble your device, follow these instructions in reverse order.