



Lenovo Thinkpad x230 Bezel Replacement

This guide shows how to remove the bezel from a Lenovo Thinkpad x230 Laptop.

Written By: Lino Virgen



INTRODUCTION

Users will learn how to remove the bezel from a Lenovo Thinkpad x230.



TOOLS:

- [Phillips #0 Screwdriver](#) (1)
 - [iFixit Opening Picks set of 6](#) (1)
-


Step 1 — Preparations



- Turn off the computer.
- Disconnect the charging cable from the computer.

⚠ Failure to unplug the cable could result in electric shock.

Step 2 — Locate the battery




- Flip the computer upside down.
- The red rectangle shows the location of the battery.

Step 3 — Unlock the left switch



- Locate the two switches that lock the battery. Push the left-hand switch outward into the "unlocked" position.

Step 4 — Remove the battery




- Now push and hold the right clip to the right while using your other hand to gently slide the battery away from the computer.

Step 5 — Bezel



- Remove the plastic screw covers with an iFixit opening pick.

Step 6



- Remove the screws (0.4, 0.5 cm) from the bottom corners of the bezel using a Phillips #0 screwdriver.

Step 7



- Carefully remove the plastic bezel cover using an iFixit opening pick.

To reassemble your device, follow these instructions in reverse order.