




Lenovo U31-70 Hard drive/SSD Replacement

How to replace the Hard Drive or SSD. Same for Lenovo U41-70.

Written By: fixer





INTRODUCTION

How to replace the Hard Drive or SSD. Same for Lenovo U41-70.

TOOLS:

- Phillips #0 Screwdriver (1)

Step 1 — Removing Backplate Screws




- Phillips Screw Driver
- 10 Screws to hold Backplate

Step 2 — Remove Backplate



- Lift up Backplate from side closest to you

Step 3



- From top to bottom
- WiFi Card
- CPU
- RAM
- Hard Drive
- Battery

Step 4 — Remove Hard Drive Screws




- Remove 4 Hard Drive Screws
- Top left Screw might have a Warranty-Seal

Step 5 — Remove Hard Drive



- Lift flap and pull down and up

Step 6 — Install new Hard Drive



- Remove Mounting Bracket from Hard Drive

To reassemble your device, follow these instructions in reverse order.