



Lenovo X200 Battery Replacement

This guide will tell you how to replace a battery in a Lenovo Thinkpad X200. Before starting the repair, make sure that it is a X200.

Written By: Legendary Ocelot





PARTS:

- [Thinkpad X200 Battery \(1\)](#)

Step 1 — Battery



- Flip the Laptop over. It should look similar to this.

Step 2 — Battery Removal



- Pull the 2 tabs that looks like it holds the battery in place. Pull the battery out while holding the clips in that position.

Step 3 — Finished



- This is what the battery should look like.

To reassemble your device, follow these instructions in reverse order.