![iFixit logo]

Lenovo Y50-70 Touch Fan Replacement

This guide will show you the steps on how to replace the Lenovo Y50-70 Touch fans.

Written By: Vivian

www.iFixit.com

INTRODUCTION

This guide will walk you through two basic steps: removing the back and removing the fan.

TOOLS:

- Phillips #1 Screwdriver (1)

PARTS:

- 2.25W Sunon Cooling Fan (1)
  Cooling Fan
  Serial Number: EG60070S1-C060-S99

This document was generated on 2019-09-24 03:05:24 PM (MST).

Step 1 — Back

- Remove all twelve 6 mm screws from the back of the laptop using a Phillips #1 screwdriver.

 - (i) Apply a lot of pressure to prevent the screws from stripping.

 - ⚠ Make sure to turn off the computer first!

Step 2

- Gently pull the back cover off the laptop. It should come off easily.

Step 3 — Fan

- Remove the three 3.5 mm screws from the fan with a Philips #1 screwdriver.

Step 4

- Pull the wire tabs up one at a time to separate them from the motherboard.

  ⚠ Do not pull too hard on the wire tabs. It may damage the connection between the wires and motherboard.

This document was generated on 2019-09-24 03:05:24 PM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 4 of 6

Step 5

- Remove the black and white antenna cables from the wireless card.

- ⚠ Do not pull too hard on the antenna cables, as it might damage the connection to the wireless card.

Step 6

- Lift up the fan slightly.

- Gather the antenna cables(black and white) and speaker wires (red, black, blue, and white). Carefully move them away from the fan.

Step 7

- Lift the fan off of the laptop.

To reassemble your device, follow these instructions in reverse order.

www.iFixit.com