Lenovo Yoga 3 Pro Back Panel Replacement

This guide will show you how to remove the back panel of the Lenovo Yoga 3 Pro.

Written By: Nathan Lui

INTRODUCTION

This guide will show you how to remove the back panel of the Lenovo Yoga 3 Pro. The back panel covers and protects all the internal components of the laptop. Only remove this cover if you need to service or replace major internal components inside of the laptop.

TOOLS:

- T5 Torx Screwdriver (1)

This document was generated on 2020-01-25 07:14:37 AM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 2 of 4

Step 1 — Back Panel

- Flip the laptop so that the back panel is facing up.

- Remove the ten 4.0mm T6 Torx screws from the back of the laptop.

Step 2

- Gently lift the back cover off of the laptop.

This document was generated on 2020-01-25 07:14:37 AM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 3 of 4

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-01-25 07:14:37 AM (MST).