




# Lenovo Yoga 710-14IKB Trackpad Replacement

Guide to replace the trackpad of your Lenovo Yoga 710-141KB.

Written By: Chuefeng Vang




## INTRODUCTION

This guide will teach you to remove and replace your trackpad.

### TOOLS:

- [T4 Torx Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)
- [Phillips #00 Screwdriver](#) (1)
- [JIS #1](#) (1)

## Step 1 — Back Cover



⚠ Ensure your device is completely OFF before starting this guide.

- Use a Torx T4 screwdriver to unscrew the nine 5 mm screws holding the cover in place.

- Use a Torx T4 screwdriver to unscrew the 8 mm screw in the center.

☒ When, reassembling, make sure not to tighten the screws too much or you may risk cracking the plastic cover.

## Step 2



- Use the plastic opening tool to pry the cover up and away from the laptop, starting at one end and working your way around the cover.

ⓘ The cover is large and flat and made of thin plastic. It cracks easily, so make sure not to pry too hard.

## Step 3 — Battery



- Use a Phillips #00 screwdriver to remove the four 3 mm screws holding the battery in place.
- Be careful not to cross-thread the screws. Also, don't let the screws fall down into the laptop case.

## Step 4




- Lift the battery connector straight up away from the board using your fingers or an opening tool.

## Step 5





- Remove the battery.

## Step 6 — Trackpad



- Use the Phillips #1 screwdriver to take off the three 3mm screws.



## Step 7



- Grip the blue tab and pull out.


⚠ Careful to not pull too hard, there is a chance of damaging the tab.

## Step 8



- Lift off the layer of tape from the trackpad.

## Step 9



- Push out the trackpad.

To reassemble your device, follow these instructions in reverse order.