




Lenovo Yoga 910-13IKB Speakers Replacement

This guide describes how to replace the speakers for the Lenovo Yoga 910-13IKB.

Written By: Connor Dilloughery




INTRODUCTION

If your Lenovo Yoga 910-13IKB speakers sound muffled, distorted, or fail to produce any sound at all, access and replace them using this guide. This is a simple procedure, only requiring a JIS #00 screwdriver.

TOOLS:

- JIS #00 Screwdriver (1)


Step 1 — Speakers



⚠ Completely power off the laptop and disconnect it from any power sources before beginning.


- Turn the laptop over and remove the ten 3mm JIS #00 screws along the perimeter of the bottom panel.
- Remove the back panel.

Step 2



- Remove the four silver 3mm JIS #00 screws holding the speakers in place.


Step 3



- Lift up the speaker from the corner of the device.
- Pull gently on the bundled cable connector at the top of the speaker.

⚠ Pull evenly on the width of the cable so that no individual wire is overly strained.

Step 4



- Repeat step three for the speaker on the opposite side of the device.

To reassemble your device, follow these instructions in reverse order.