



Lenovo Yoga C930-13IKB Back Cover Replacement

This guide is used to take off or replace the back cover for a Lenovo Yoga C930-13IKB.

Written By: Hanna Lazkani



INTRODUCTION

This guide can be used if the device's back cover is damaged or replacement inside the device is needed. If you are unsure about what you need to replace underneath the back cover, visit this [troubleshooting page](#).

Everything required to begin getting inside your device is here. For this guide, you will need a plastic opening tool and a T5 Torx screwdriver.

Make sure to turn off the device before taking it apart.

TOOLS:

- [T5 Torx Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)

Step 1 — Back Cover



- Flip the device over so that the underside is facing up.
- Remove the six 3.5 mm T5 Torx screws.

Step 2



- Pry off the back cover using the plastic opening tool.
- Loosen the back cover in multiple spots using the opening tool, then remove the whole back.

(i) You may have to run the plastic tool along the edges until you find a small gap to separate the back cover from the laptop.

⚠ Do not use a metal tool when working with your device.

Step 3



- Carefully lift the cover off with your hands.

To reassemble your device, follow these instructions in reverse order.