



# Logitech G710+ Disassembly

Complete Disassembly of the Logitech G710+

Written By: thefluffyfist



 **TOOLS:**

- Phillips #1 Screwdriver (1)

**PARTS:**


- Spudger (1)

## Step 1 — Body




- Use a PH1 screw driver to remove the 14 screws holding the body together.
  - Gently pry the two halves of the case apart.
- (i)* You will probably break off some of the clips but, the screws work fine at holding the keyboard together. aka you don't need the clips.

## Step 2 — Mother board



- Unscrew the one screw holding on the ground and pull out the cables.
- A good way of getting the cables out is by putting a screwdriver right there and twisting.
- Unscrew this screw

## Step 3 — Scroll Wheel



- The light thing comes out with a wiggle.
- The scroll wheel on the other is harder because you have to melt or brake the supports off.
- Then you have to get the wheel out which comes out with a very gentle wiggle.

## Step 4 — Pads



- You can then take off the little pads

To reassemble your device, follow these instructions in reverse order.