




# Logitech Harmony 950 Battery Replacement

This guide will show how to replace the battery in the Logitech Harmony 950 Remote Control.

Written By: Blake Sanborn



## INTRODUCTION

If the battery to the remote is not working properly, follow this guide to replace it.

### TOOLS:

- [iFixit Opening Tools](#) (1)
- [Phillips #0 Screwdriver](#) (1)

## Step 1 — Battery



*(i)* Make sure the remote control is powered off before starting.

- Use the Opening Tool to open the port cover at the bottom of the remote control.
- Bend the cover back to gain easy access to the screws.

## Step 2



- Use the Phillips #0 Screwdriver to remove the (2) two 6mm screws.
- Pull the bottom cover off of the remote control.

## Step 3



- Use the Phillips #0 Screwdriver to remove the (2) two 6mm screws.
- There should be a gap on each side to fit the Opening Tool. Use the Opening Tool to open the back cover (Soft Touch cover) using the gap.

## Step 4



- Use the Opening Tool to lift the battery out of the case.
- Gently pull the cable out of the socket to unplug the battery.

 Be careful not to damage any part of the remote when pulling the cable out.

To reassemble your device, follow these instructions in reverse order.