




Logitech K120 Keyboard Kickstand Replacement

Sometimes, your kickstand breaks. This guide will help you replace your kickstand.

Written By: Marcus Liu



Step 1 — Remove The Old Kickstand



- Pinch the kickstand and pull it out.

Step 2 — Insert The New Kickstand



- Slide one of the pins into the keyboard.
- Snap the other pin into the keyboard.

The kickstand of the Logitech K120 is easy to replace.