



Logitech M515 (Couch) Mouse

Over time, dirt and dust can get inside the M515 and clog up the buttons and scroll wheel. Here's how to open it up, I recommend using some compressed air to clean it.

Written By: Anna Sweetnam



INTRODUCTION

Taking the outer shell off is very easy and all of the internals are visible when it is removed.

TOOLS:

- Phillips #1 Screwdriver (1)

PARTS:

- Compressed Air (1)

Step 1 — Removing the outer shell




- Remove the battery hatch and batteries.

Step 2



- Remove the single Phillips screw located between the battery sockets.

Step 3



- Lift the rear of the top case of the mouse and slide forward. It should be fairly easy to release.

To reassemble your device, follow these instructions in reverse order.