



# MSI GE72 6QF Apache Pro Battery Replacement

This guide shows how to locate and remove the battery of an MSI GE72 6QF Apache Pro for possible replacement.

Written By: Hovik Aklyan



## INTRODUCTION

This guide shows how to locate and remove the battery of a MSI GE72 6QF Apache Pro for possible replacement.

### **TOOLS:**

- [Phillips #1 Screwdriver \(1\)](#)

### **PARTS:**

- [MSI BTY-M6H Battery \(1\)](#)

## Step 1 — Battery



**⚠** Make sure the laptop is off and unplugged (not charging).


- With the laptop closed and upside down, unscrew the nineteen 5.5mm Phillips #1 screws that keep the back cover in place.

## Step 2




- Using your fingers, gently loosen the edges of all four sides of the back cover.
- Gently pull off the back cover.

## Step 3



- Unscrew the single 5.5mm Phillips #1 screw keeping the battery secure.

## Step 4



- Grab the battery with your fingers and gently pull it up and away from the rest of the laptop.

To reassemble your device, follow these instructions in reverse order.