




MSI GP60 2PE Leopard Hard Drive Replacement

A guide that will help you replace your hard drive.

Written By: Zoey Calcagno



INTRODUCTION

Looking for a guide to help you replace your MSI GP60 2PE Leopard hard drive? This is the guide for you. Simply follow a few steps and your hard drive will be out in no time.

TOOLS:


- [Phillips #00 Screwdriver](#) (1)
- [Phillips #0 Screwdriver](#) (1)

Step 1 — Battery



- Flip MSI GP60 2PE Leopard, so that the back is facing up.

Step 2



- Find the unlock tab located on the upper right side of the device, then slide it to the right.

Step 3



- Slide and hold the release tab on the left side of the battery, so that you can remove the battery.

Step 4



- While holding the release tab, remove the battery slowly.

Step 5 — Back Panel



- Flip the device over so the back is facing up.

Step 6



- Remove the four 5mm screws from the back of the device using a Phillips #00 screwdriver.
- There is a screw located under the battery; lift the battery up to access it.

Step 7



- Once all four screws are removed, lift the back off.

Step 8 — Hard Drive



- Remove the two 5 mm black screws on the right hand side with a Phillips #0 screwdriver.

Step 9



- Lift the hard drive, then remove from the device. There is a black strip of plastic attached to make the process easier.

To reassemble your device, follow these instructions in reverse order.