



Mac mini Mid 2010 RAM Replacement

Upgrade the RAM for overall faster performance.

Written By: Andrew Bookholt



INTRODUCTION

Removing the RAM on the mid 2010 Mac mini is an easy task that requires no tools.



PARTS:

- [Mac mini Mid 2010 Memory Maxxer RAM Upgrade Kit](#) (1)
- [PC3-8500 1 GB RAM Chip](#) (1)
- [PC3-8500 2 GB RAM Chip](#) (1)
- [PC3-8500 4 GB RAM Chip](#) (1)
- [PC3-8500 8 GB RAM Chip](#) (1)

Step 1 — Bottom Cover




- Place your thumbs in the depressions cut into the bottom cover.
- Rotate the bottom cover counter-clockwise until the white dot painted on the bottom cover is aligned with the ring inscribed on the outer case.

Step 2



- Tilt the mini enough to allow the bottom cover to fall away from the outer case.
- Remove the bottom cover and set it aside.

Step 3 — RAM



- Release the tabs on each side of the RAM chip by simultaneously pushing each tab away from the RAM.
- These tabs lock the chip in place and releasing them will cause the chip to "pop" up.
- After the RAM chip has popped up, pull it straight out of its socket.

 Repeat this process if a second RAM chip is installed.

To reassemble your device, follow these instructions in reverse order.