



MacBook Air 11" Late 2010 Lower Case Replacement

Remove the lower case on your MacBook Air 11" Late 2010.

Written By: Andrew Bookholt



INTRODUCTION

Remove the lower case to access the internals of your MacBook Air.

TOOLS:

- P5 Pentalobe Screwdriver Retina MacBook Pro and Air (1)

PARTS:

- MacBook Air 11" (Late 2010/Mid 2011) Lower Case (1)
- MacBook Air Rubber Feet (1)

Step 1 — Lower Case



 Before proceeding, close your computer and lay it on a soft surface top-side down.

- Remove the following ten screws:
 - Two 8 mm 5-point Pentalobe screws
 - Eight 2.5 mm 5-point Pentalobe screws

 The special screwdriver needed to remove the eight 5-point Pentalobe screws can be found [here](#).

Step 2



- Wedge your fingers between the display and the lower case and pull upward to pop the lower case off the Air.
- Remove the lower case and set it aside.

To reassemble your device, follow these instructions in reverse order.