



Magic Bullet MB1001B Base Gear Replacement

Replacing the base gear on your Magic Bullet MB1001B.

Written By: Jackson Wiley



INTRODUCTION

Is your base gear worn down or broken? This guide will help you replace the base gear.

TOOLS:

- **Flathead Screwdriver** (1)
- **Slip Joint Pliers** (1)

Step 1 — Base Gear



- Use pliers to grip the gear inside of the top of the device.
- You may have to remove a sticker that is covering the slit at the center of the bottom before completing the next step.
- Insert a flathead screwdriver into the slit at the bottom of the device while still holding the pliers in place gripped on the gear.
- Lay the device on its side. Holding the screwdriver stationary to hold the bottom side in place, use the pliers to unscrew the gear by turning the pliers CLOCKWISE.

To reassemble your device, follow these instructions in reverse order.