



Magic Bullet NutriBullet Pro Rubber Gasket Replacement

Use this guide to replace a damaged rubber gasket on a Magic Bullet NutriBullet Pro for a tight seal that prevents leaks. If the seal is cracked or ripped it will continue to leak.

Written By: Andrew Pana



This document was generated on 2019-10-04 08:03:03 AM (MST).

INTRODUCTION

This guide will demonstrate how to replace a damaged rubber gasket on the blender blade lid of your cup. The rubber gasket is responsible for sealing the cup from leaking. Other possible problems can be found in our [Troubleshooting Guide](#).

TOOLS:

- Tweezers (1)

Step 1 — Rubber Gasket



- Unscrew the blending blade lid from the cup.

Step 2



- Use tweezers to peel back the rubber gasket that surrounds the inner ring of the lid.

To reassemble your device, follow these instructions in reverse order.