



Maintenance Guide for Sony SGPT211US/S Tablet

This guide includes directions on installing & removing the battery pack, motherboard installation (Replacing the SSD), and changing the date or time. This guide was written by: Joel De La Garza, Bryant Reynolds, Juan Domingo Salazar, and Aaron Clamon.

Written By: Aaron

INTRODUCTION

This guide includes directions on installing & removing the battery pack, motherboard installation (Replacing the SSD), and changing the date or time. This guide was written by: Joel De La Garza, Bryant Reynolds, Juan Domingo Salazar, and Aaron Clamon.

TOOLS:

- Pro Tech Toolkit (1)

Step 1 — Installing and Removing the Battery Pack



- Push the two buttons on the back of the device to open the bottom cover.
- Orient the contacts so that the battery pack is inserted face up.
- Close the bottom cover.
- To remove the tablet's battery pack push the two tabs down.
- Remove the battery.

Step 2 — Motherboard Installation- (Replacing the SSD)



- To get to the SSD the tablet must be open: Note this will void your device's warranty.
- Open your tablet with care. The device should open when a slight amount of pressure is applied.
- After removing the back cover and the battery pack take a Phillips head screwdriver and remove the remaining screws that hold the encasement of the tablet's inner housing.
- With the tablet now open, and the display screens lying face down, you will need to remove a few more cables before you can remove the motherboard.
- Keep the screws safe and gently pry the motherboard away from the case.
- Once you're done, gently flip the motherboard over. The SSD can be found once you gently flip the motherboard over.
- You will find the SSD attached to the motherboard with one or two screws. Once both are detached, the small storage device will spring up. Lightly pull out the card, insert the larger upgrade, and then replace the screws, securing it in place.

Step 3 — How to change the date or time



- Select the Home icon in the upper-right corner of the desktop home screen.
- Tap the Apps icon in the Apps screen.
- Choose the Settings icon in the Settings screen. Tap to select Date & Time in the Date & Time screen.
- Tap Set date to change the displayed date.
- Tap Set time to change the displayed time. Once all desired changes have been made, tap Set.
- Tap Select time zone to change the displayed time.
- Use 24-hour format to have the time displayed in the 24-hour (military time) format.
- Select date format to change the format in which the date is displayed.