



Makita Chain Saw EA6100PR 2017 Brake Release

Prerequisite guide only! Releases the chain brake for a Makita chainsaw

Written By: Arthur Shi



INTRODUCTION

This is a prerequisite guide! This guide is part of an another procedure and is not meant to be used alone.

Step 1 — Release the chain brake



- Pull the hand guard towards the tubular handle until you hear a click to release the chain brake.

To reassemble your device, follow these instructions in reverse order.