



Makita DT01 Battery Replacement

This guide shows you how to replace the battery on your Makita DT01 drill.

Written By: Victoria Scira



INTRODUCTION

This guide will help you remove the battery from your drill.

Step 1 — Battery



- Lay the device down on its side.

Step 2



- Pinch the indents on both sides of the battery.

Step 3



- Pull the battery out of the drill
 - Recharge or completely replace the battery
- ⚠** Make sure that the battery is removed before further working on the drill. This is so the drill doesn't accidentally activate.

To reassemble your device, follow these instructions in reverse order.