



Makita DT01 The trigger Replacement

This guide walks you through the steps required to replace the trigger on the Makita DT01 drill.

Written By: Ya'Rub Al Manwari



INTRODUCTION

This guide walks you through the steps required to replace the trigger on the Makita DT01 drill.

TOOLS:

- JIS Driver Set (1)

Step 1 — The trigger




- Take out the battery.

Step 2




- Unscrew the six screws on the top of the drill.

Step 3



- Place the big trigger out to be able to remove the other trigger smoothly.

Step 4



- Take out the broken trigger.

To reassemble your device, follow these instructions in reverse order.