



Marshall Kilburn Battery Replacement

How to replace a rechargeable battery pack for the Marshall Kilburn bluetooth speaker.

Written By: Kai Hattan



INTRODUCTION

The rechargeable battery used in this device is one of the components most likely to fail. Fortunately the replacement process is simple and straightforward. Follow this guide for a pain-free battery replacement experience.

TOOLS:

- [T10 Torx Screwdriver](#) (1)
- [Spudger](#) (1)

Step 1 — Battery



- Place the unit face down as shown in the picture, exposing the battery cover.
- Remove the two 4.0mm long screws holding the cover on using a T10 driver.

Step 2



- Remove the battery cover using a fingernail or nylon spudger.

Step 3



- Remove the battery and unplug the power lead.

To reassemble your device, follow these instructions in reverse order.