



# Matsunichi MarquisPad MP977 Front Facing Camera Replacement

This guide will demonstrate how to replace the front facing camera in the Matsunichi MarquisPad MP977.

Written By: Kathryn Sherlock



 **TOOLS:**

- [Phillips #00 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)

## Step 1 — Front Facing Camera




- Remove the two screws using a PH #00 Phillips head screw driver.

## Step 2



- Then, place the device face down on a flat surface.
- Insert one of the wide tipped, plastic opening tools into the top of the left speaker slot.  
**⚠** Be sure not to puncture the covering of the speaker.
- After, pry the back plate open and slide the tool in a clockwise direction, moving it along the opening between the device and the back plate until you reach the power button.

## Step 3




- Insert opening tool into the right speaker slot.
- Then, pry open the back plate of the device , and slide the tool counter clockwise along the device until you reach the charging port.

## Step 4





- Remove the back plate and place it to the side of the device.

## Step 5




- With the same screw driver, PH #00 Phillips head, remove the seven screws holding in the motherboard.
- (i)* Place the screws somewhere safe where they wont fall.

## Step 6



- Pull the camera optic fiber out of the slot it is in causing the flap to pop right open.
- ⚠** Be sure not to damage the camera port.

## Step 7



- Last, Insert the new camera into the pinhole camera slot.

To reassemble your device, follow these instructions in reverse order.