Mattel Loopz Batteries Replacement

This guide will show how to replace the AA batteries on a Mattel Loopz.

Written By: Jake Tragesser

This document was generated on 2019-09-22 01:47:36 PM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 1 of 3

INTRODUCTION

The Mattel Loopz uses AA batteries for power. To replace these batteries a Phillips head screwdriver is required.

🔧 TOOLS:

- Phillips #2 Screwdriver (1)

⚙ PARTS:

- AA Batteries (4)

This document was generated on 2019-09-22 01:47:36 PM (MST).

Step 1 — Batteries

- Use a No. 2 Phillips head screwdriver to take out the 1/4" screw that holds the battery cover in place on the bottom of the device.

Step 2

- Take out the 4 AA Batteries.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-09-22 01:47:36 PM (MST).