




MiTM Pressure Washer CM1400HDEC1 2017

Electrical Box Removal

This pre-req guide will show you how to remove the electrical box on the CM1400HDEC1 201 MiTM electric pressure washer.

Written By: Taylor Dixon



This document was generated on 2020-04-05 09:02:52 PM (MST).


INTRODUCTION

This is a pre-req guide for the removal of the electrical box on the CM1400HDEC1 201 MiTM electric pressure washer.

TOOLS:



- 4 mm Hex Key (1)

Step 1 — Unscrew the electrical box



- Remove the four 59.2 mm-long 4 mm hex socket bolts from the electrical box.

Step 2 — Lower the electrical box



- Carefully pull the electrical box away from the engine until you have enough space to work inside it, making sure not to strain the cables that are still connected inside.

ⓘ If you have trouble lowering the electrical box, you can [disconnect the green power cord wire](#) for more slack.

To reassemble your device, follow these instructions in reverse order.