



Microsoft Natural Multimedia Keyboard

disassembly and cleaning

A guide showing how to disassemble and clean a Microsoft Natural Multimedia Keyboard.

Written By: asvnix



INTRODUCTION

A guide showing how to disassemble and clean a Microsoft Natural Multimedia Keyboard.

TOOLS:



- Essential Electronics Toolkit (1)

Step 1 — Microsoft Natural Multimedia Keyboard disassembly and cleaning



- A guide showing how to disassemble and clean a Microsoft Natural Multimedia Keyboard.
- You will need a spudger to remove the keys. An IC mounting tool can be helpful in replacing them.

Step 2



- Use the flat end of a spudger to pop the keys off the keyboard.

Step 3



- Wider keys will have a retaining bar, take note of how they come off to make reassembly easier.
- Continue removing keys.

Step 4



- Remove the 10 screws from the bottom of the keyboard.
- Remove the upper button assembly.

Step 5



- Use the tip of a spudger to push the upper button assembly buttons out from the back.

Step 6



- Remove the flexible keypad from the key caddy assembly.
- The key caddies can be washed in the sink.

Step 7



- The keys can also be washed.
- *i* Remove the metal retaining clips before washing to prevent rust.

To reassemble your device, follow these instructions in reverse order.